Hardware Installation

1. Connect your mouse to the USB port on your computer.



Software Installation

1. Put the CD into the CD-ROM.
2. Follow the instructions on the screen to finish the software installation.
   Note: Download the latest software update from www.geniusnet.com

Mouse Mode Button Definition

Slide the bottom cover of the mouse down.



1. **Left Button:** Provides traditional mouse functions like click, double click and drag.
2. **Magic-Roller:** Press the "Magic-Roller" to surf the Internet and Windows documents.
3. **Right Button:** Provides traditional mouse click functions.

Cam Mode Button Definition

Slide mouse bottom cover up. Software must be installed.

1. **Snap Button:** Capture image function (for right hand use).
2. **LED:** Will turn on when the mouse is in cam mode.
3. **Video Button:** Press video button to start recording videos.



Warning: (Troubleshooting)

Do not use the optical/laser mouse on a desk which is made of glass or mirror.